



## Οδηγίες χρήσης

### Oval Bräter

Παρακαλώ διαβάστε προσεκτικά αυτές τις οδηγίες χρήσης πριν την πρώτη χρήση της γάστρας και κρατήστε τις για μελλοντική αναφορά. Η γάστρα είναι κατάλληλη για ηλεκτρικό φούρνο και φούρνο αερίου. Δε μπαίνει σε φούρνο μικροκυμάτων.

### Γενικές συμβουλές ασφαλείας

Μην επιτρέπετε πρόσβαση των παιδιών σε υλικά συσκευασίας (σακούλες, πλαστικά κ.λπ.) γιατί μπορεί να προκληθεί ατύχημα.

Πάντα να φοράτε ειδικά προστατευτικά γάντια φούρνου ή παρόμοιο προστατευτικό εξοπλισμό όταν σηκώνετε ή μετακινείτε τη γάστρα από τον φούρνο. Μη θερμαίνετε τη γάστρα όταν είναι άδεια.

### Προετοιμασία και χρήση

Απομακρύνετε όλες τις ετικέτες και τα αυτοκόλλητα. Πριν την πρώτη χρήση, καθαρίστε με ζεστό σαπουνόνερο, ξεπλύνετε και στεγνώστε. Μπορεί να θερμανθεί μέχρι τους 250°C. Είναι κατάλληλη για ηλεκτρικό φούρνο και φούρνο αερίου. Δε μπαίνει σε φούρνο μικροκυμάτων. Μην κόβετε μέσα στη γάστρα για να μην καταστρέψετε την επίστρωση και μη χρησιμοποιείτε μεταλλικά εργαλεία. Να χρησιμοποιείτε εργαλεία από πλαστικό ανθεκτικό στη θερμότητα ή ξύλο. Καθαρίζετε το προϊόν μετά τη χρήση.

### Καθαρισμός μετά τη χρήση

Μουσκέψτε τη γάστρα για μερικά λεπτά πριν το πλύσιμο. Απομακρύνετε από το σκεύος τυχόν υπολείμματα φαγητού με ένα μαλακό σφουγγάρι ή βούρτσα –αν τρίψετε με σύρμα ή σκληρά λειαντικά καθαριστικά θα γρατσουνίσετε και θα καταστρέψετε την εμαγιέ επίστρωση. Πλύνετε τη γάστρα με ζεστό σαπουνόνερο, ξεπλύνετε και στεγνώστε. Το προϊόν είναι κατάλληλο για πλύσιμο σε πλυντήριο πιάτων.

**ΜΑΙΝΗΤΙΚΗ Α.Ε**  
ΕΙΣΑΓΩΓΕΣ - ΑΝΤΙΠΡΟΣΩΠΕΙΕΣ

ΘΕΣΣΑΛΟΝΙΚΗ: ΘΕΣΗ «ΜΠΙΛΛΙΑ», ΠΕΡΙΟΧΗ ΑΕΡΟΔΡΟΜΙΟΥ  
57001 – ΘΕΡΜΗ, Τ.Θ. 60541 ΤΗΛ: +302310805980 FAX: +302310805959  
ΑΘΗΝΑ: Β. ΑΛΕΞΑΝΔΡΟΥ 39, 12131 – ΠΕΡΙΣΤΕΡΙ  
ΤΗΛ: +302109329061-2 FAX: +302109373632

E-mail: [info@juopro.gr](mailto:info@juopro.gr)

<https://www.juopro.gr>



## Instruction manual

### Oval Bräter

Please read this instruction manual carefully before the first use and keep it for future reference. The roaster is suitable for gas and electric oven. Do not use it in a microwave oven.

#### General safety advice

Do not allow children to access packaging material (bags, foils, etc.) because accidents may occur. Keep the children away from the packaging material.

Always use oven gloves or similar when lifting or moving the hot roaster around the oven. Do not heat the roaster empty.

#### Preparation and use

Remove labels, wash in hot soapy water, rinse and dry. The roaster can be heated up to 250°C. It is suitable for gas and electric oven. Do not use it in a microwave oven. Do not cut food directly inside the roaster in order to not damage the coating. Use heat resistant plastic or wood kitchen utensils. Clean after use.

#### Cleaning after use

Soak the roaster for a few minutes before washing. Remove food deposits with a nylon pan scourer or brush –scrubbing with steel wool or harsh abrasive cleaners will scratch the enameled surface. Wash roaster in hot soapy water, rinse and dry thoroughly. The product is suitable for dishwasher.

  
**ΜΑΙΝΗΤΙΚΗ Α.Ε.**  
ΕΙΣΑΓΩΓΕΣ - ΑΝΤΙΠΡΟΣΩΠΕΙΕΣ

THESSALONIKI: THESI "BILIA", AIRPORT AREA

57001 – THERMI, P.O. Box 60541 TEL: +302310805980 FAX: +302310805959

ATHENS: V. ALEXANDROY 39, 12131 – PERISTERI

TEL: +2109329061-2 FAX: +2109373632

E-mail: [info@juopro.gr](mailto:info@juopro.gr)

<https://www.juopro.gr>